#### HUSKY ONE YEAR LIMITED WARRANTY PROGRAM

This Husky Power Product is warranted by Home Depot, to the original purchaser only, to be free of defects in materials and workmanship for one year from the date of purchase without additional charge. If you believe that this unit is defective during its original one-year warranty period, return the unit with proper proof of purchase to the Home Depot store, or you may send the product to Husky Power Products at the address below.

The warranty does not extend to subsequent purchasers or users. Husky Power Products will not be responsible for any amount of damage in excess of the retail purchase price of the product under any circumstances. Incidental and consequential damages are specifically excluded from coverage under this warranty.

This product is not intended for commercial use. This warranty does not apply to accessories or damage to units from misuse or incorrect installation/connection. Misuse includes wiring or connecting to improper polarity power sources.

RETURN/REPAIR POLICY: Defective products, other than accessories, may be returned to Husky Power Products Any defective product, other than accessories, that is returned to Husky Power Products within 30 days of the date of purchase will be replaced free of charge. If such a product is returned more than 30 days but less than one year after the purchase date, Husky Power Products will repair the unit or, at its option, replace it free of charge.

If the unit is repaired, new or reconditioned replacement parts may be used, at Husky Power Product's option. A unit may be replaced with a new or reconditioned unit of the same or comparable design. The repaired or replaced unit will then be warranted under these terms for the remainder of the warranty period. The customer is responsible for the shipping charges on all returned items after 30 days. During the warranty period, Husky Power Products will be responsible for the return shipping charges.

LIMITATIONS: This warranty does not cover accessories, bulbs, fuses and batteries, defects resulting from normal wear and tear (including chips, scratches, abrasions, discoloration or fading due to usage or exposure to sunlight), accidents, damage during shipping to our service facility, alterations, unauthorized use or repair, neglect, misuse, abuse, failure to follow instructions for care and maintenance, fire, flood and Acts of God.

If your problem is not covered by this warranty, call our Technical Support Department toll free at (800) 916-7004. for general repair information and charges, if applicable.

STATE LAW RIGHTS: This warranty gives the purchaser specific legal rights; other rights, which vary from state to state, may apply. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the exclusions or limitations stated herein may not apply.

TO REQUEST WARRANTY SERVICE FOR THIS PRODUCT: Contact Husky Power Products Technical Support by telephone, fax or mail. We suggest that you keep the original packaging in case you need to ship the unit. When returning a product, include your name, address, phone number, dated sales receipt (or copy) and a description of the reason for return and product serial number. After repairing or replacing the unit, we will make every effort to return it to you within four weeks.

WARRANTY ACTIVATION: Please complete Warranty Activation Card and mail to Husky Power Products. Enter "HSK176" as Model and "2.25 Million Power Series™ Rechargeable Spotlight" as Product Type. All Husky Power Product products must be registered within 30 days of purchase to activate this warranty. Mail the completed registration form, along with a copy of the original sales receipt to:

ATTN.: CUSTOMER SERVICE / HUSKY POWER PRODUCTS 4140 SW 30th Avenue, Ft. Lauderdale, FL 33312 • TOLL FREE: (800) 916-7004

WARRANTY IS NON-TRANSFERABLE AND NON-REFUNDABLE

BD062205



# 2.25 Million Power Series™ Rechargeable Spotlight Cordless • Rechargeable



# WARRANTY INFORMATION

# IMPORTANT SAFETY INFORMATION, SAVE THESE INSTRUCTIONS

TO REDUCE THE RISK OF INJURY, USER MUST READ AND UNDERSTAND THIS INSTRUCTIONAL MANUAL. THIS MANUAL CONTAINS IMPORTANT INFORMATION REGARDING THE OPERATION AND WARRANTY OF THIS PRODUCT. PLEASE RETAIN FOR FUTURE REFERENCE.

# **IMPORTANT SAFETY INFORMATION**

- Although the HUSKY 2.25 Power Series Cordless Rechargeable Spotlight can be recharged using either AC or DC power sources, it is not designed to operate directly from the supplied AC recharge adapter. Doing so may result in damage to the unit, and will also void the warranty.
- 2. You CAN CHARGE and OPERATE the Spotlight directly from the supplied DC adapter (recharge/power adapter).
- 3. Do not use charging systems other than those supplied by the manufacturer.
- 4. Do not leave the Spotlight charging for more than 24 hours (AC method) or 6 hours (DC Method).
- 5. Do not completely discharge the battery before recharging. Deep discharge will decrease battery life.
- 6. Recharge the battery in a well ventilated area.
- 7. Never look directly into the light.
- 8. Use caution when handling the light as the lens becomes hot during use.
- 9. Store with Spotlight turned OFF and trigger lock ON.
- 10. Store with area light in handle turned OFF.
- 11. Do not operate Spotlight with lens against flammable materials.
- 12. Keep Spotlight away from children; it is not a toy.

#### **WARNING**

RISK OF FIRE OR ELECTRIC SHOCK: Do not plug in a detachable power supply without bulb lens.

#### **GENERAL PRECAUTIONS**

- All halogen lights give off heat. Never place the light face down on any surface when lit.
- Never look directly into light or shine the light into another person's eyes.
- Replace bulb with type indicated in specifications or a 12 volt H3 quartz halogen bulb.
- Do not immerse this spotlight in water.
- Use in a dry location only.

Read This User's Manual Before Using This Unit.

# **SAVE THESE INSTRUCTIONS**

i

#### TABLE OF CONTENTS

Introduction
Features
AC and DC Charging/Recharging
Checking Battery Charge Status
120 Volt AC Charging
12 Volt DC Charging
Operating Instructions
Using the Spotlight
Using the Auxiliary LED Area Lights
Hands-Free Operation
Care and Maintenance
Replacement Parts
Spotlight Bulb Replacement
Fuse Replacement
Battery Disposal
Specifications

#### INTRODUCTION

Thank you for purchasing the **HUSKY 2.25 Million Power Series<sup>TM</sup> Cordless Rechargeable Spotlight**, with a powerful quartz halogen spotlight and two LED area lights that provide up to 35 hours of continuous use. Please read this guide carefully to ensure optimum performance and to avoid damage to the unit.

### **FEATURES**

- The tough, weatherproof **HSK176** is built for rugged, outdoor use
- Powerful quartz halogen bulb illuminates up to one mile and easily penetrates rain, fog or smoke with 10 times the power of an automobile headlight
- Two long-life auxiliary LED area lights that provide up to 35 hours of continuous use
- Computer-designed parabolic reflector
- Cordless operation allows complete freedom of movement
- Engineered to be easy to operate without sacrificing light intensity
- Pistol grip handle design fits comfortably in the hand
- Locking trigger ON/OFF switch delivers an instant beam, locks for continuous beam
- 3-LED Battery Status Indicator
- May be charged from either 120 volt AC power source (using the built-in AC charger) or 12 volt DC power source (charging adapter included)

Figure 1



Figure 2



#### AC AND DC CHARGING/RECHARGING

# **Checking Battery Charge Status**

Pressing the Auxiliary LED Area Light Power Button turns on the Battery Status Panel LEDs. Recharge the unit when the red LED (only) is lit.

# 120 Volt AC Charging

To recharge, plug a standard 120 volt household extension cord into the 120 volt AC charger on the back of the unit (see Figure 2). Charge until the green Battery Charge Indicator LED lights indicating the unit is fully charged.



#### **A WARNING**

Do not recharge for more than 24 hours maximum using the 120 volt AC method.

# 12 Volt DC Charging

Plug the supplied 12 Volt DC Charging Adapter into the 12 Volt DC Recharge Port, located at the bottom of the pistol grip handle (see Figure 1).



Insert the power plug into the accessory outlet of your vehicle or other 12 volt DC power source. Charge until the green Battery Charge Indicator LED lights indicating the unit is fully charged.

Note: Some vehicles must have the ignition turned on to power the vehicle's accessory outlet.

#### **AWARNING**

Do not recharge for more than 6 hours maximum using the 12 volt DC method.

#### **OPERATING INSTRUCTIONS**

# **Using the Spotlight**

The Spotlight is controlled by the Trigger on the top front of the pistol grip (see Figure 1). Squeezing the Trigger turns the Spotlight ON; releasing the Trigger turns the Spotlight OFF.

For continuous operation, use the Trigger Lock Switch. Simply squeeze the Trigger and firmly slide the Trigger Lock Switch located on the side of the handle into the "locked" position. The Spotlight will remain ON until the Trigger Lock Switch is returned to the "unlocked" position.

# **Using the Auxiliary LED Area Lights**

The LED area lights provide up to 35 hours of continuous utility lighting and are ideal for:

- for roadside repairs
- for work areas
- for campsites
- for power outages
- for general use as a flashlight, etc.

The ON/OFF button for the area lights is located at the back of the unit below the battery charge LEDs. Pressing this button toggles the LED area lights between ON and OFF.

# **Hands-Free Operation**

# **Using the Built-In Carry Lanyard**

The carry lanyard may be used to suspend the spotlight from a branch, hook or other convenient object. Adjust the slide on the cords to keep the lanyard secure around the supporting object.

# Using the Built-In Carry Handle/Workstand

Turn the spotlight upside-down, and rest it on the built-in carry handle/workstand. The spotlight and/or area utility light may now be used hands-free.



#### **CARE AND MAINTENANCE**

#### **Replacement Parts**

For replacement parts (bulbs, fuses, adapters, etc.), contact Customer Service toll free at (800) 916-7004. There are no user serviceable parts inside this unit except the bulb.


# **Spotlight Bulb Replacement**


To replace the H3 type 12 volt bulb, you will need a small Phillips type screwdriver and a replacement bulb. Bulb life can be shortened by installing a bulb with dirt or fingerprints on it. The bulb can be wiped clean with a cloth moistened with alcohol. During bulb installation, avoid touching the glass part of the bulb. (See Figures 3A and 3B for details.)

- 1. Disconnect the unit from any charging adapter.
- 2. Push back the rubber bezel toward the back of the spotlight to reveal two small Phillips screws in the retaining ring.
- 3. Using the screwdriver, remove (counterclockwise) the two screws. Set them aside.
- 4. Lift off the retaining ring, glass lens and rubber "O" ring and set them aside.
- 5. Carefully remove the reflector and bulb assembly.
- 6. Disconnect the bulb wire from the red power wire.
- 7. Unsnap the hairpin retaining wires from the reflector's flange.
- 8. Using the screwdriver, loosen the retaining screw to remove the bulb from the reflector (no need to completely remove this screw).
- 9. Lift out the bulb and the attached wire and set the burned-out bulb aside.
- 10. Insert the replacement bulb into the reflector's flange.
- 11. Put back and secure the hairpin retaining wires.
- 12. Connect the bulb power wire to the red power wire.
- 13. Tighten the retaining screw on the flange.
- 14. Place the reflector in position in the body of the spotlight.

- 15. Replace the rubber "O" ring in the groove around the perimeter of the reflector.
- 16. Replace glass and retaining ring so that the screw holes are aligned.
- 17. Secure retaining ring with two screws.
- 18. Replace rubber bezel by sliding forward to the front of the spotlight.
- 19. Operate switch to ensure proper operation of spotlight.

#### Figure 3A





# **DC Charging Adapter Fuse Replacement**

The plug of the DC Charging Adapter is equipped with an 8 amp cartridge fuse. If this fuse blows, there may be a short circuit in the power cord or lamp assembly. The fuse will blow if the battery is connected with reverse polarity. The fuse is accessed by unscrewing (counterclockwise) the tip of the large DC plug. Check the fuse with an ohmmeter or other continuity checker. If the fuse is open, investigate why it blew

and correct the problem before replacing the fuse. Reassemble the DC plug and power the lamp from a 8 amp or greater 12 volt power supply.

# Fuse Replacement (DC Accessory Adapter)

- 1. Remove plug from accessory outlet. Remove the gold cap by turning counterclockwise and lifting off.
- 2. Remove center pin and spring. Remove fuse.
- 3. Replace fuse with same type and size fuse (8 amp).
- 4. Replace center pin and spring inside plug.
- 5. Replace gold cap by turning clockwise.

# **Battery Disposal**

Non-spillable sealed lead-acid battery — This battery is fully recyclable and should be accepted at any location that accepts common automotive starter batteries. Examples of places that accept these batteries are: county or municipal recycling drop-off centers, scrap metal dealers, and retailers who sell automotive replacement lead acid starter batteries. For more information on recycling this recycling this battery, call toll-free (877) 288-7722.



#### **AWARNING**

Before disposing of the battery, protect exposed terminals with heavy-duty tape to prevent shorting. (Shorting can result in injury or fire.)

Do not expose battery to fire or intense heat as it may explode.

#### **SPECIFICATIONS**

AC Charger: 120 volt

Halogen bulb size: H3 Type 12 Volt

Fuse: 8 amp cartridge fuse

6 7